

FORD MONDEO 2.0Ltr TDCi (upto 2007) EXCEPT ST MODELS
MJS UPATED REPLACEMENT INTERCOOLER



1&2) STANDARD INTERCOOLER - UNDO CLIPS, REMOVE M6 BOLTS, REMOVE INTERCOOLER



3&4) BOTTOM INTERCOOLER MOUNT AS STANDARD (O/S) CUT DOWN AS SHOWN IN PIC 4



5&6) BOTTOM INTERCOOLER MOUNT AS STANDARD (N/S) CUT DOWN AS SHOWN IN PIC 6



7&8) INTERCOOLER RUBBER PIPEWORK AS STANDARD (N/S) CUT DOWN AS SHOWN IN PIC 8



9&10) INTERCOOLER RUBBER PIPEWORK AS STANDARD (O/S) CUT DOWN AS SHOWN IN PIC 10



11) INSTALL UPATED INTERCOOLER

FITTING INSTRUCTIONS:

- * REMOVE UNDERTRAY (refer to owners manual)
- * REMOVE HEADLIGHTS (*Not necessary, but recommended for easier installation*)
- * REMOVE FRONT BUMPER

* FOLLOW STAGES AS ABOVE

* AFTER INSTALL, REFIT HEADLIGHTS, FRONT BUMPER & UNDERTRAY

TOOLS NEEDED:

- FLEXI HOSE CLIP TOOL
- 10mm SOCKET
- HACKSAW (hoses & intercooler mount)

IF YOU REQUIRE ANY FURTHER ASSISTANCE PLEASE CONTACT
A MEMBER OF STAFF WHO WILL BE HAPPY TO HELP
T/F: 01621 850431 email: info@mjsfabrication.co.uk